

*DryBell*

## **Footswitch F1-L**

The F-1L Footswitch is a new accessory for the Vibe Machine V-2 pedal. It is designed for multiple purposes, specifically for the V-2: Tap Tempo, Leslie FAST/SLOW mode, Two Speed mode or to engage the Cancel function. It is a simple latching footswitch wired tip to sleeve. Naturally, it can be used with any other pedal which uses a footswitch option.

You will find its small size (5 x 5cm / 2 x 2") very practical for use on any type of pedalboard. We use only high quality components (Neutrik jacks/Alpha switches) in the F-1L. It is a very solid and durable footswitch made out of aluminum. We also use graphite metallic finish on both the F-1L Footswitch and the Vibe Machine V-2.

In order to connect the F-1L Footswitch to the Vibe Machine V-2 PEDAL+ expression input, use a simple mono patch cable (a stereo patch cable will also work).